

EZ Garbage Disposal Cleaner



Directions for Use

For larger commercial disposal, use 2 pouches. For residential disposal, use 1 pouch. Use several times per week or when soils build up or odors require freshening.

- To begin, ensure disposal is empty and turned off.
- Run warm/hot water in the sink with disposal.
- Toss the appropriate number of pouches into the disposal. Do not open pouch.
- Turn disposal on for several seconds.
- Turn disposal and water off. Blue probiotic cleaning foam will rise from the drain.
- Once the foam has receded, rinse the sink clean.

Tech Specs

Bacteria Count	10 Million CFU per Gram
Bacterial Type	Non-Pathogenic
DSL	Yes
Color	Blue
Fragrance	Apricot
Gram Negatives	Not Present
pH	6 - 9.5
Temperature Range	20 - 40 Celsius
Warranty	2 Years
Storage Temperature	10 - 20 Celsius
Storage Humidity	30 - 60%

Foaming Probiotic Garbage Disposal Cleaner and Freshener

EZ Garbage Disposal Cleaner is an effective foaming probiotic cleaner and freshener for all types of garbage disposals.

The pleasant fragrance along with the probiotic cleaning action leave tough-to-reach disposal sidewalls, blades, and pipes clog free and smelling fresh.

Features

- Water-soluble packaging for simple dosing and application
- Helps prevent downstream clogging
- Powerful formula effective at degrading buildup in restaurant disposals
- Leaves kitchen sinks clean and running smoothly

Available In

30 - 2 oz. Pouches Item #GTP328P57