

# QUAT-STAT™ 5 DISINFECTANT



## 5 Minute Alkaline Disinfectant

Quat-Stat 5 provides hospital disinfection with a contact time of just 5 minutes. This one-step registered cleaner and disinfectant offers excellent cleaning performance on a wide variety of surfaces. It cleans, disinfects and deodorizes.

### Features

- 5-minute dwell time
- Effective yet economical; ½ oz. per gallon dilution (1:256)
- Efficacy against Norovirus
- Save labor cost with 5-minute dwell time
- Can be used through an auto-scrubber

### Available In

4 - 1 Gal. Bottles Item #34104-00

4 - 2 L Fast Draw Item #34147-00

6 - 32 oz. Dosing Bottles Item #34148-00

55 Gal. Drum Item #34155-00

### Directions for Use

Dilution: Disinfection (1:256) ½ oz. per gallon of water. DIRECTIONS FOR USE: It is a violation of Federal law to use this product in a manner inconsistent with its labeling. Preparation of Disinfectant Use-Solution: Mix ½ oz. per gallon of water 1:256

000 For heavy duty use, mix 2 oz. per gallon of water 1:64000. DISINFECTION/VIRUCIDAL: Apply use-solution to hard, nonporous surfaces, thoroughly wetting surfaces with a cloth, mop, sponge, sprayer or by immersion. Treated surfaces must remain wet for 5 minutes. Wipe dry with a cloth, sponge or mop or allow to air dry. For heavily soiled areas, a preliminary cleaning is required. For sprayer applications, use a coarse spray device. Spray 6 - 8 inches from the surface; rub with a brush, sponge or cloth. Do not breathe spray. Rinse all surfaces that come in contact with food such as countertops, appliances, tables and stovetops with potable water before reuse. Do not use on utensils, glassware and dishes. To disinfect food processing facilities: Spray surfaces with solution and allow to remain wet for 5 minutes. Rinse food contact surfaces with potable water prior to reuse. Prepare a fresh solution daily or more often if the solution becomes visibly dirty or diluted. This product is effective in one step against *Candida albicans* at ½ oz. per gallon in 250 ppm hard water and 5% serum. Treated surfaces must remain wet for 5 minute contact time. This product is not for use on medical device surfaces. \*KILLS HIV AND HBV AND HCV ON PRE-CLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS in health care settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids, and in which the surfaces/objects likely to be soiled with blood or body fluids are associated with the potential for transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS) or Hepatitis B Virus (HBV) or Hepatitis C Virus (HCV). SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 OR HBV OR HCV ON SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS. Personal protection: Clean-up must always be done wearing protective gloves, gowns, masks and eye protection. Cleaning Procedure: Blood and other body fluids containing HIV-1 or HBV or HCV must be thoroughly cleaned from surfaces and objects before application of this product. Contact Time: Leave surface wet for 5 minutes with a ½ oz. per gallon use-solution. Disposal of Infectious Material: Blood, body fluids, cleaning materials and clothing must be disposed of according to local regulations for infectious waste disposal. NON-ACID TOILET BOWL AND URINAL DISINFECTANT/CLEANER DIRECTIONS: Remove gross filth prior to disinfection. From Concentrate: Add ½ oz. to the bowl and mix. Brush over exposed surfaces and under the rim, allow to stand for 5 minutes and flush. From Use Solution: Empty toilet bowl or urinal and apply ½ oz. per gallon use-solution to exposed surfaces and under the rim with a cloth, mop, sponge or mechanical spray. Brush or swab thoroughly; allow to stand for 5 minutes and flush. TO CLEAN AND DEODORIZE: Mix ½ oz. of Quat-Stat™ 5 per gallon of water or 1 - 4 oz. per gallon to clean and deodorize surfaces. Apply using a sprayer. Wipe or allow to air dry.

### Tech Specs

Dilution:	½ oz. per gal (1:256)
EPA Reg. No	6836-361-4170
Color	Purple
Fragrance	Lavender
pH concentrate	Alkaline
Warranty	1 year