



Customer Service: [1-888-GO-BETCO](tel:1-888-GO-BETCO)
8AM - 5PM ET, Monday - Friday

Equipment Tech Support [1-877-856-5954](tel:1-877-856-5954)
8AM - 4:30PM ET, Monday - Friday

Sure Bet™ II Foaming Disinfectant



One-Step Acid Cleaner, Disinfectant, *Virucide, Mildewstat, and Deodorizer

Sure Bet II disinfects, cleans, and deodorizes in one labor-saving step. This formulation penetrates and dissolves soap scum, ground in dirt and grime, mineral deposits, rust, lime soap build up, hard water stains, and kills household germs. Cleans and shines without abrasive scouring action. Deodorizes too, leaving your bathroom smelling fresh.

Features

Effective as a disinfectant against *Pseudomonas aeruginosa*, *Staphylococcus aureus* and *Streptococcus pyogenes*. Removes hard water deposits, rust, mineral stains and lime soap buildups. Quickly removes soap scum from shower tile, fiberglass, chrome and glass, toilet bowls, sinks, tubs and spas.

Available In

55 Gal. Drum Item #31455-07

55 Gal. Drum Item #31455-00

4 - 1 Gal. Bottles Item #31404-00

12 - 32 oz. Bottles Item #31412-00

4 - 2 L FastDraw Item #31447-07

4 - 1 Gal. Bottles Item #31404-07

4 - 2 L FastDraw Item #31447-00

Directions for Use

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

PREPARATION OF DISINFECTANT USE-SOLUTION: Add 4 oz. per gallon of water (for 400 ppm water hardness).

DISINFECTION DIRECTIONS: Apply use-solution with a cloth, sponge, or sprayer or by soaking until surfaces are thoroughly wet. Treated surfaces must remain wet for 10 minutes. Wipe dry with a clean cloth or sponge or let air dry. For sprayer applications, use a coarse spray device. Spray with quick full strokes 6 - 8 inches from surface. Rub with a brush, sponge or cloth. Do not breathe spray. After use, close nozzle. For heavily soiled areas, a preliminary cleaning is required. Prepare a fresh solution daily or more often if use solution becomes diluted or soiled. Rinse all surfaces that come in contact with food such as countertops, appliances, tables and stovetops with potable water before reuse. This product must not be used to clean utensils, glassware and dishes. This product is not to be used as a terminal sterilant/high level disinfectant on any surface or instrument that (1) is introduced directly into the human body, either into or in contact with the bloodstream or normally sterile areas of the body, or (2) contacts intact mucous membranes but which does not ordinarily penetrate the blood barrier or otherwise enter normally sterile areas of the body. This product may be used to pre-clean or decontaminate critical or semi-critical medical devices prior to sterilization or high level disinfection.

***VIRUCIDAL DIRECTIONS:** Follow Disinfection Directions. Treated surfaces must remain wet for 1 minute. Use a 30-minute contact time against Foot and Mouth Disease. Allow surfaces to air dry.

MOLD AND MILDEW CONTROL DIRECTIONS: Add 3 - 4 oz. per gallon of water to inhibit the growth of mold and mildew and their odors on hard, nonporous surfaces. Thoroughly wet all treated surfaces completely. Let air dry. Repeat application weekly or when growth or odor reappears. ***KILLS HIV-1 ON PRECLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS** in health care settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 (HIV-1) (associated with AIDS).

SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 ON SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.

Personal Protection: Clean up must always be done wearing protective gloves, gowns, masks and eye protection.

Cleaning Procedure: Blood and other body fluids containing HIV must be thoroughly cleaned from surfaces and objects before application of Betco Sure Bet II.

Contact Time: Leave surface wet for 1 minute. Use a 30-minute contact time against Foot and Mouth Disease. Use a 10-

minute contact time for disinfection against all other bacteria claimed.

Disposal of Infectious Materials: Blood, body fluids, cleaning materials and clothing must be autoclaved and disposed of according to local regulations for infectious waste disposal.

HEAVY DUTY CLEANER DIRECTIONS: Use 8 oz. per gallon of water for heavy duty cleaning.

TO CLEAN AND DEODORIZE: Use 1:32 dilution. Apply to wet the surface thoroughly. Let stand for at least one minute, rinse with water or allow to air dry.

Tech Specs

Color	Green
Foaming	High
Fragrance	Citrus
Lime Soap Removal	Excellent
pH	<1
Warranty	1 year